



RECHARGEABLE CO2 MONITOR AND DATA LOGGER XT-10

The XT-10 CO2 Monitor measures and records carbon dioxide, temperature and relative humidity to monitor indoor air quality at home or at work.

FEATURES

- Large display shows CO2, Temperature and % Relative Humidity levels in real time
- NDIR CO2 sensor for fast, accurate, and stable readings
- Visual and audible alarm functions
- Built-in data logger with free software – Windows Only
- Powered by USB or rechargeable batteries
- Fresh air or automatic baseline calibration
- Clean, modern desktop design
- **Display:**
 - Clock
 - Calendar
 - Alarm
 - Temperature
 - Humidity
 - CO2

SPECIFICATIONS

- **Measurement Range:** 0-9,999 ppm
- **Accuracy:** $\pm 70\text{ppm} \pm 3\%$ reading value (at $< 5,000\text{ppm}$)
- **Response Time:** 2 minutes @ 90% charge
- **Temperature Range:** -10 to 70°C ($14 - 158^\circ\text{F}$)
- **Temperature Accuracy:** $\pm 0.3^\circ\text{C}$ @ $10-55^\circ\text{C}$
- **Humidity Range:** 0.1-99% non-condensing (CO2 cannot be read under 20% RH)
- **Humidity Accuracy:** $\pm 3\%$ RH
- CO2 Air Quality Warning Alarm
- **Data Log Memory:** 12,700 data points
- **Size:** 4.2 x 4.2 x 2.3 in (106 mm x 106 mm x 58 mm)

INCLUDES

- Monitor
- 110/240 VAC USB Wall Adapter (USA)
- USB Cable
- User's Manual

ADDITIONAL DEVICES

- [XT-5 Carbon Dioxide Desktop Monitor](#)
- [RAD-0301 CO2Mini Indoor Air Quality Monitor](#)
- [Tongdy - WiFi Indoor Air Quality Monitor](#)
- [RAD-0201 cSense Large Character Wall CO2 Monitor](#)

INDUSTRIES



Home



Office



Classroom



Commercial