



CO2Meter, Inc. is including these notes about the pump in your unit and its proper operation as reference material. By taking note of these pump specifications and use notes, your company can ensure long term operation of the unit you have purchased.

The information presented in this notice is based on CO2Meter's technical data and test results of similar units. This information is offered as an aid to help in the selection of products and long term care/use of the unit.

CO2meter does not warranty, guarantee, or assume any obligation or liability for any pump or unit containing a pump that is deemed to have exceeded its stated life/hour expectancy, or if it has been operated in a manner inconsistent with the operating recommendations made below.

About the Pumps that CO2Meter Utilizes

PMP-0010

The PMP-0010 is a 1,000 hr. pump. The pump will last approximately 41 days if run continuously. Avoid use of this pump without filters. If your application involves any of the following items the pump will not function to its full life expectancy: Corrosive gasses, water, condensation, high temperature, and high pressure (no more than 6 PSI).

PMP-0012

The PMP-0012 is a 10,000 hr. pump. The pump will last approximately 415 days if run continuously. Avoid use of this pump without filters. If your application involves any of the following items the pump will not function to its full life expectancy: Corrosive gasses, water, condensation, high temperature, and high pressure (no more than 6 PSI).

PMP-0013

The PMP-0013 is a 10,000 hr. pump. The pump will last approximately 415 days if run continuously. Avoid use of this pump without filters. If your application involves any of the following items the pump will not function to its full life expectancy: Corrosive gasses, water, condensation, high temperature, and high pressure (no more than 6 PSI).

Additional Info

For additional information on these pumps' operating specifications please visit www.co2meter.com/products/gas-sampling-pump.

CO2Meter reccommends that you visit CO2Meter.com to purchase the following items: Filter & Water Traps for Sensor Pumps.



PM-0010



PM-0012



PM-0013

